

**PF580L066011**

[Stampa etichette scatola](#) | [Stampa etichette argentate](#) | [Italian version](#) | [Vista commerciale](#)

**Notes****Handle type**

Free movement knob



PRVV5019PE - INTERR. VERDE


**Additional pushbutton****Movement type**

Stepped movement, spring return

**Guides**Lever guide type:  Free  Cross  Verticale  Horizontal**PRGL6666PE**Speed positions:  3 pos.  6 pos.**Cams and potentiometers**

## Cams list:

- 1: [CKR60006](#)
- 2: [CKR60008](#)



- 3: CKR60007
- 4: CKR60009
- 5: CKR60006
- 6: CKR60008
- 7: CKR60007
- 8: CKR60009

