## 8. AC911 Bus Connector, CAN

## 8.1 General Information

The bus connector enables you to:

- Exchange a CAN node without shutting down the network since the connection is not broken, and
- Change the termination resistance quickly and easily (e. g. if the last node in a network is removed).

## 8.2 Order Data




Table 391: AC911 order data

## 8.3 Technical Data

Product ID	AC911
Lines	Connection for two bus lines
Terminating Resistance	120 $\Omega$ - can be switched on
Stress Relief	Built-in

Table 392: AC911 technical data